


A7116AUTO 71 TYPE AUTOMATIC AIR STAPLER

For replacement parts contact your usual Tacwise supplier.

Exploded view drawing



Item	Description	Item	Description
1	Cap	51	O-Ring
2	O-Ring	53	Nose Cover
3	O-Ring	54	Split Pin
4	Piston Ram Assembly	55	Split Pin
5	O-Ring	56	O-Ring
6	Cylinder	57	End Cap
7	Bumper	59	Trigger Valve A
8	Trigger Valve Set	61	Double Trigger Latch Spring
9	Trigger Valve Spring	62	Double Trigger
10	O-Ring	63	Pin
11	Trigger Valve	64	E-Ring
12	O-Ring	65	Automatic Adjust Switch Set
13	O-Ring	66	O-Ring
14	O-Ring		
15	Trigger Valve Stem		
16	Trigger Valve Guide		
17	O-Ring		
18	Hex. HD Soc. Screw & Washer		
20	Hex. HD Soc. Screw		
21	Nose		
22	Nose Plate		
23	Magazine Cover		
24	Pusher Spring		
25	Magazine Cover		
26	Pusher		
27	Rear Magazine Bumper		
28	Hex. Soc. FT HD Screw		
29	Bottom HD Soc. Screw		
30	Magazine Retainer		
31	Step Pin		
32	Trigger		
33	Seal		
34	Body		
35	Magazine Latch Spring		
36	Magazine Latch		
37	Air Plug		
38	Pin		
39	E-Ring		
42	Trigger Valve Plate		
43	O-Ring		
44	O-Ring		
45	O-Ring		