FCN55V 55mm COIL NAILER

For replacement parts contact your usual Tacwise supplier.

Exploded view drawing



Item	Description
1	Screw
2	Bushing
3	Exhaust Cover
4	Seal
5	Muffler
6	Screw
7	Spring Washer
8	Cylinder Cap
9	Gasket
10	Spring
11	O-ring 42.8 x 2.65
12	Valve
13	O-ring 58.7 x 3.5
14	Valve Seat
15	Collar
16	Cylinder Seal
17	O-ring 45.3 x 4
18	Piston Assembly
19	Cylinder
20	O-ring 54 x 2.5
21	O-ring 52.4 x 2.5
22	Restrictive Plate
23	O-ring 81.8 x 2.65
24	Bumper
25	Body
26	O-ring 53 x 1.5
27	Nut
28	Washer
29	Protector
30	O-ring 7.5 x 1.5
31	Nose
32	Washer
33	Pin
34	Safe Bracket
35	Safe Sleeve
36	Safe Guide
37	Spring
38	Bracket
39	Adjusting Stem

Item	Description
40	O-ring 6.4 x 1.5
41	Handwheel
42	Adjusting Seat
43	Screw
44	Pin
45	Spring Pin 2.5 x 20
46	Stopped Hook
47	Spring
48	Washer
49	Handwheel Assembly
50	Spring
51	Stopped Hook Pin
52	Latch
53	Washer
54	Spring Washer
55	Screw
56	Spring Pin 3 x 28
57	O-ring 20.3 x 2.5
58	Valve Guide
59	O-ring 20.3 x 1.5
60	O-ring 9.5 x 1.9
61	O-ring 10.3 x 1.9
62	Trigger Valve Seat
63	O-ring 12.8 x 1.9
64	Spring
65	O-ring 5.5 x 1.5
66	Trigger Valve Stem
67	Trigger Valve Guide
68	Spring
69	Locking washer
70	Rotating Shaft Bushing
71	Trigger
72	Steel Ball
73	Spring
74	Rotating Shaft Pin
75	Spring Pin
76	Trigger Spring
77	Spring Pin
79	Piston

Item	Description
80	Feed Hook Pin
78	O-ring 12.3 x 1.9
81	O-ring 24.3 x 2.8
82	Spring
83	Piston Bumper
84	Cover
85	Locking washer
86	Spring
87	Feed Hook
88	Screw
89	Soft Grip Sleeve
90	O-ring 48.8 x 2.5
91	End Cap
92	Air Plug
93	Upper Nail Housing
94	Spring Pin
95	Adjuster Nut
96	Adjuster Plate
97	Adjuster Bushing
98	Adjusting Stem
99	Lower Nail Housing
100	Pin
101	Spacer
102	Screw