


# A71AUTO AUTOMATIC AIR STAPLER

For replacement parts contact your usual Tacwise supplier.

## Exploded view drawing



Item	Description	Item	Description
101	Deflector	228	Trigger Valve Head C
102	Packing	229	Spring
103	Seal	230	Trigger Valve Head
104	O-Ring	231	O-Ring
105	Cylinder	232	O-Ring
106	O-Ring	233	Trigger Valve Stem A
107	Cylinder Ring	301	Gun Body Unit
108	O-Ring	302	O-Ring
109	Driver Unit	303	End Cap
110	Bumper	306	Guide Plate
111	Driver Guide	307	Hex. Soc. HD. Bolt
201	O-Ring	308	Muffler
202	Trigger Valve Head B	401	Bolt Assembly
203	O-Ring	402	Hex. Soc. HD. Bolt
204	O-Ring	403	Driver Guide Cover
205	Collar	404	Gasket
206	O-Ring	405	Magazine B
207	Valve Plunger A	406	Stopper
208	O-Ring	407	Hex. Soc. HD. Bolt
209	O-Ring	408	Pusher
210	Cushion	409	Latch Spring Bushing
211	Plunger Cap	410	Spiral Pins
212	O-Ring	411	Rear Plate
213	O-Ring	412	Spring Pin
214	Valve Plunger B	413	Pull Spring
215	Ball	414	Spring
216	Plunger Cap	415	Latch
217	O-Ring	416	Magazine A
218	Trigger Valve Head D	417	Spring Pin
219	O-Ring	418	Hex. Soc. HD. Bolt
220	Round Cross Screw	419	Positioning Sheet
221	Trigger	420	Driver Guide
222	Trigger Pivot Pin	421	Roller
223	Urethane Retainer	422	Counter Sunk Screw
224	Adjust Axle		
225	Anchor Block		
226	O-Ring		
227	O-Ring		