


## JCN90XHH 90mm COIL NAILER

For replacement parts contact your usual Tacwise supplier.

### Exploded view drawing



Item	Description	Item	Description	Item	Description
101	Counter Sunk Screw	210	Trigger Valve Head	427	Safety B
102	Deflector Pad	211	Spring Pin	428	Hex. Soc. HD. Bolt
103	Deflector	212	Spring Pin	429	Flat Washer
104	Rubber Pad	213	Trigger Unit	430	Screw Fixing Seat
105	Grommet	214	Spring Pin	431	Safety A
107	Cap	216	Trigger Pivot Pin	432	Pin
108	Hex. Soc. HD. Screw	217	Urethane Retainer	433	Magazine Cover
109	Positioning Axis	301	Gun Body Unit	434	Fixed Ring
110	Spring	302	O-Ring	435	Spring Base A
111	Hex. Soc. HD. Screw	303	End Cap	436	Pull Spring
112	Compression Spring	304	Air Plug	437	Spacer
113	HD. Valve Piston	306	Filter	438	Adjust Post
114	O-Ring	401	O-Ring	439	Magazine Case
115	O-Ring	402	O-Ring	440	Latch Spring Bushing
116	O-Ring	403	Nose Piece	441	Flat Washer
117	Valve	404	Bolt Assembly	442	Hex. Soc. HD. Bolt
118	Collar	405	Pu Retainer	443	S-Ring
119	Seal	406	Feed Finger	444	Spring Base
120	Half Round HD. Hex. Bolt	407	Feed Finger Spring	445	Safety Cover
121	Cylinder Cap Seal	408	Pin Feed Piston	446	Bolt Cap
122	O-Ring	409	O-Ring	447	Muzzle Protector
123	Driver Unit	410	Feed Piston	448	Bolt Assembly
124	Press Ring	411	O-Ring	449	Pu Retainer
125	Cylinder	412	Feed Piston Spring	450	Safety Spring
126	O-Ring	413	Feed Bumper		
127	Cylinder Ring	414	Feed Piston Cap		
128	Cylinder Spacer	415	C-Ring		
129	O-Ring	416	Stopper Finger Spring		
130	Bumper	417	Door		
131	Press Ring	418	Nail Stop		
201	O-Ring	419	Spiral Pins		
202	O-Ring	420	Fixed Ring		
203	Plunger Cap	421	Door Latch		
204	Valve Plunger	422	Latch Spring		
205	O-Ring	423	Fixed Pin		
206	O-Ring	424	Door Shaft Pin		
208	Plunger	425	Safety Guide		
209	O-Ring	426	Safety Spring		